



Metall- und Druckgusswaren GmbH

Dessestraße 7  
D-87600 Kaufbeuren

[www.simm-zinkdruckguss.de](http://www.simm-zinkdruckguss.de)  
[www.simm-metallwaren.de](http://www.simm-metallwaren.de)

# CATALOGUE

## Settings with prongs

for SWAROVSKI standard program



Fabrikation  
Made in Germany  
seit 1955

+49 8341 9668 13-0

[info@simm-metallwaren.de](mailto:info@simm-metallwaren.de)



## Settings with prongs for SWAROVSKI standard program

### Sitemap

#### - Round

- [SW 1088](#)
- [SW 1122](#)
- [SW 1201](#)
- [SW 1383](#)
- [SW 1401](#)
- [SW 1681](#)
- [SW 1695](#)

#### - Oval

- [SW 4120](#)
- [SW 4122](#)
- [SW 4127](#)
- [SW 4128](#)
- [SW 4142](#)
- [SW 4160](#)
- [SW 4161](#)
- [SW 4162](#)
- [SW 4196](#)

#### - Navette

- [SW 4200](#)
- [SW 4224](#)
- [SW 4227](#)
- [SW 4228](#)
- [SW 4230](#)

#### - Pear

- [SW 4320](#)
- [SW 4322](#)
- [SW 4327](#)
- [SW 4328](#)
- [SW 4329](#)
- [SW 4331](#)

#### - Square

- [SW 4418](#)
- [SW 4428](#)
- [SW 4447](#)
- [SW 4481](#)

#### - Rounded square

- [SW 4470](#)
- [SW 4471](#)
- [SW 4483](#)

#### - Baguette

- [SW 4500](#)
- [SW 4501](#)
- [SW 4505](#)
- [SW 4524](#)
- [SW 4527](#)
- [SW 4547](#)
- [SW 4565](#)

#### - Octagon

- [SW 4600](#)
- [SW 4610](#)
- [SW 4627](#)
- [SW 4675](#)
- [SW 4678](#)
- [SW 4480](#)
- [SW 4499](#)

#### - Triangle

- [SW 4717](#)
- [SW 4722](#)
- [SW 4727](#)

#### - Heart

- [SW 4809](#)
- [SW 4827](#)
- [SW 4831](#)

#### - Fancy

- [SW 4460](#)
- [SW 4485](#)
- [SW 4683](#)
- [SW 4699](#)
- [SW 4707](#)
- [SW 4719](#)
- [SW 4731](#)
- [SW 4739](#)
- [SW 4745](#)
- [SW 4757](#)
- [SW 4760](#)
- [SW 4767](#)
- [SW 4790](#)
- [SW 4795](#)
- [SW 4799](#)

**Material:**

Tombak MS 85 ÖkoTex 100 Standard

**Minimum quantity:**

raw: 500 Pieces

plated: 1 KG

**Search option:**

Please press „CTRL + F“ to open the search window.

**REACH REGULATION**

We confirm that our raw-material does not contain any of the substances of high concern (SVHC) and all our products are conform to the REACH regulation.

**CHEMICAL-COMPOSITION Tombac (alloy: CuZn15)**

	Einheit	Min.	Sollwert Max.	Istwert Max.
CU Kupfergehalt	%	84	86	84,572
FE Eisengehalt	%		0,05	0,0042
PB Bleigehalt	%		0,05	0,0162
NI Nickelgehalt	%		0,2	0,0115
SN Zinngehalt	%		0,05	0,0327
ZN Zinkgehalt	%		Rest	
AL Aluminiumgehalt	%		0,02	0,0005
SI Siliziumgehalt	%			0,0005




## Settings with prongs: **Round**

Open search window:  
Ctrl + F



closed back



sew-on settings

The pictures show  
the item in size  
M/SS 40

Size	Product code	Type	Swarovski no.
M/SS 6	01150-00-00	closed back	1088
M/SS 8	00200-00-00	closed back	1088
M/SS 10	00202-00-00	closed back	1088
M/SS 12	00204-00-00	closed back	1088
M/SS 15	00205-00-00	closed back	1088
M/SS 19	00207-00-00	closed back	1088
M/SS 22	00208-00-00	closed back	1088
M/SS 25	00209-00-00	closed back	1088
M/SS 30	00210-00-00	closed back	1088
M/SS 35	01703-00-00	closed back	1088
	01703-50-00	sew-on settings, closed back	
M/SS 40	01702-00-00	closed back	1088
	01702-50-00	sew-on settings, closed back	






## Settings with prongs: **Round**

Open search window:  
Ctrl + F




closed back



sew-on settings

The pictures show  
the item in size  
M/SS 40

Size	Product code	Type	Swarovski no.
			
M/SS 6	01150-00-00	closed back	1088
M/SS 8	00200-00-00	closed back	1088
M/SS 10	00202-00-00	closed back	1088
M/SS 12	00204-00-00	closed back	1088
M/SS 15	00205-00-00	closed back	1088
M/SS 19	00207-00-00	closed back	1088
M/SS 25	00209-00-00	closed back	1088
M/SS 30	00210-00-00	closed back	1088
M/SS 35	01703-00-00	closed back	1088
	01703-50-00	sew-on settings, closed back	
M/SS 40	01702-00-00	closed back	1088
	01702-50-00	sew-on settings, closed back	

[< Sitemap](#)



## Settings with prongs: **Round**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
SS 48

Size	Product code	Type	Swarovski no.
SS 12	00211-00-00 00211-10-00 00211-40-00	closed back open back sew-on settings, open back (4x1)	1088
SS 15	00212-00-00 00212-10-00 00212-40-00	closed back open back sew-on settings, open back (4x1)	1088
PP 32	01689-00-00 01689-10-00 01689-40-00	closed back open back sew-on settings, open back (4x1)	1088
SS 18	00206-00-00 00206-10-00 00206-40-00	closed back open back sew-on settings, open back (4x1)	1088
SS 19	00213-00-00 00213-10-00 00213-40-00	closed back open back sew-on settings, open back (4x1)	1088
SS 25	00214-00-00 00214-10-00 00214-40-00	closed back open back sew-on settings, open back (4x1)	1088
SS 30	00215-00-00 00215-10-00 00215-40-00	closed back open back sew-on settings, open back	1088
SS 35	00216-00-00 00216-10-00 00216-40-00	closed back open back sew-on settings, open back	1088
SS 40	00217-00-00 00217-10-00 00217-40-00	closed back open back sew-on settings, open back	1088
SS 45	00218-00-00 00218-10-00 00218-40-00	closed back open back sew-on settings, open back	1088

[Sitemap](#)



## Settings with prongs: **Round**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
SS 48

Size	Product code	Type	Swarovski no.
SS 47	01574-00-00	closed back	1088
	01574-10-00	open back	
	01574-40-00	sew-on settings, open back	
SS 48	00333-00-00	closed back	1088
	00333-10-00	open back	
	00333-40-00	sew-on settings, open back	
SS 50	00219-00-00	closed back	1088
	00219-10-00	open back	
	00219-40-00	sew-on settings, open back	





## Settings with prongs: **Round RIVOLI**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
14 mm

Size	Product code	Type	Swarovski no.
SS 40	01602-00-00	closed back	1122
	01602-10-00	open back	
	01602-40-00	sew-on settings, open back	
SS 47	01579-00-00	closed back	1122
	01579-10-00	open back	
	01579-40-00	sew-on settings, open back	
10 mm	01704-00-00	closed back	1122
	01704-10-00	open back	
	01704-40-00	sew-on settings, open back	
12 mm	01361-00-00	closed back	1122
	01361-10-00	open back	
	01361-40-00	sew-on settings, open back	
14 mm	01360-00-00	closed back	1122
	01360-10-00	open back	
	01360-40-00	sew-on settings, open back	
16 mm	01359-00-00	closed back	1122
	01359-10-00	open back	
	01359-40-00	sew-on settings, open back	
18 mm	01357-00-00	closed back	1122
	01357-10-00	open back	
	01357-40-00	sew-on settings, open back	

[Sitemap](#)





## Settings with prongs: **Round**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
27 mm

Size	Product code	Type	Swarovski no.
27 mm	01550-00-00	closed back	1201
	01550-10-00	open back	
	01550-40-00	sew-on settings, open back	
35 mm	01573-00-00	closed back	1201
	01573-10-00	open back	
	01573-40-00	sew-on settings, open back	



closed back



open back



sew-on settings

The pictures show  
the item in size  
14 mm

Size	Product code	Type	Swarovski no.
8 mm	01634-00-00	closed back	1383
	01634-10-00	open back	
	01634-40-00	sew-on settings, open back	
10 mm	01723-00-00	closed back	1383
	01723-10-00	open back	
	01723-40-00	sew-on settings, open back	
14 mm	01625-00-00	closed back	1383
	01625-10-00	open back	
	01625-40-00	sew-on settings, open back	

[< Sitemap](#)



## Settings with prongs: **Round**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
11,8 mm

Size	Product code	Type	Swarovski no.
8 mm	01712-00-00	closed back	1401
	01712-10-00	open back	
	01712-40-00	sew-on settings, open back	
10 mm	00218-00-00	closed back	1401
	00218-10-00	open back	
	00218-40-00	sew-on settings, open back	
11,8 mm	00219-00-00	closed back	1401
	00219-10-00	open back	
	00219-40-00	sew-on settings, open back	



## Settings with prongs: **Round**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
14 mm

Size	Product code	Type	Swarovski no.
12 mm	01361-00-00	closed back	1681
	01361-10-00	open back	
	01361-40-00	sew-on settings, open back	
16 mm	01359-00-00	closed back	1681
	01359-10-00	open back	
	01359-40-00	sew-on settings, open back	
10 mm	01574-00-00	closed back	1695
	01574-10-00	open back	
	01574-40-00	sew-on settings, open back	
14 mm	01360-00-00	closed back	1695
	01360-10-00	open back	
	01360-40-00	sew-on settings, open back	

< [Sitemap](#)



## Settings with prongs: **OVAL**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
6x4	01537-00-00	closed back	4120
	01537-10-00	open back	
	01537-40-00	sew-on settings, open back (2x1)	
8x6	00221-00-00	closed back	4120
	00221-10-00	open back	
	00221-40-00	sew-on settings, open back	
14x10	00225-00-00	closed back	4120
	00225-10-00	open back	
	00225-40-00	sew-on settings, open back	
18x13	00226-00-00	closed back	4120
	00226-10-00	open back	
	00226-40-00	sew-on settings, open back	
25x18	01046-00-00	closed back	4120
	01046-10-00	open back	
	01046-40-00	sew-on settings, open back	
8x6	01642-00-00	closed back	4122
	01642-10-00	open back	
	01642-40-00	sew-on settings, open back	
14x10,5	01643-00-00	closed back	4122
	01643-10-00	open back	
	01643-40-00	sew-on settings, open back	
18x13,5	01644-00-00	closed back	4122
	01644-10-00	open back	
	01644-40-00	sew-on settings, open back	





## Settings with prongs: **OVAL**

Open search window:  
Ctrl + F



closed back





open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
30x22	01539-00-00	closed back	 4127
	01539-10-00	open back	
	01539-40-00	sew-on settings, open back	
39x28	01565-00-00	closed back	4127
	01565-10-00	open back	
	01565-40-00	sew-on settings, open back	
6x4	01537-00-00	closed back	 4128
	01537-10-00	open back	
	01537-40-00	sew-on settings, open back (2x1)	
8x6	00221-00-00	closed back	4128
	00221-10-00	open back	
	00221-40-00	sew-on settings, open back	
10x8	00222-00-00	closed back	4128
	00222-10-00	open back	
	00222-40-00	sew-on settings, open back	
14x10	00225-00-00	closed back	4128
	00225-10-00	open back	
	00225-40-00	sew-on settings, open back	

[< Sitemap](#)



## Settings with prongs: **OVAL**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
10x8	00222-00-00	closed back	4142
	00222-10-00	open back	
	00222-40-00	sew-on settings, open back	
14x11	01654-00-00	closed back	4142
	01654-10-00	open back	
	01654-40-00	sew-on settings, open back	
18x14	01655-00-00	closed back	4142
	01655-10-00	open back	
	01655-40-00	sew-on settings, open back	





## Settings with prongs: **OVAL**

Open search window:  
Ctrl + F



closed back




open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
8x6	01708-00-00	closed back	4160
	01708-10-00	open back	
	01708-40-00	sew-on settings, open back	
10x8	01709-00-00	closed back	4160
	01709-10-00	open back	
	01709-40-00	sew-on settings, open back	
14x10	01710-00-00	closed back	4160
	01710-10-00	open back	
	01710-40-00	sew-on settings, open back	
18x13	01711-00-00	closed back	4160
	01711-10-00	open back	
	01711-40-00	sew-on settings, open back	





## Settings with prongs: **OVAL**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
27x9 mm

Size	Product code	Type	Swarovski no.
15x5	00227-00-00	closed back	4161
	00227-10-00	open back	
	00227-40-00	sew-on settings, open back	
21x7	01541-00-00	closed back	4161
	01541-10-00	open back	
	01541-40-00	sew-on settings, open back	
27x9	00228-00-00	closed back	4161
	00228-10-00	open back	
	00228-40-00	sew-on settings, open back	



closed back



open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
10x5,5	01690-00-00	closed back	4162
	01690-10-00	open back	
	01690-40-00	sew-on settings, open back	
14x7,5	01691-00-00	closed back	4162
	01691-10-00	open back	
	01691-40-00	sew-on settings, open back	
18x9,5	01692-00-00	closed back	4162
	01692-10-00	open back	
	01692-40-00	sew-on settings, open back	



< [Sitemap](#)





## Settings with prongs: **OVAL**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
23x20	01592-00-00	closed back	4196
	01592-10-00	open back	
	01592-40-00	sew-on settings, open back	
30x26	01591-00-00	closed back	4196
	01591-10-00	open back	
	01591-40-00	sew-on settings, open back	





## Settings with prongs: **Navette**

Open search window:  
Ctrl + F



closed back




open back



sew-on settings

The pictures show  
the item in size  
35x9,5

Size	Product code	Type	Swarovski no.
11x3	00392-00-00	closed back	4200
	00392-50-00	sew-on settings, closed back	
15x4	00487-00-00	closed back	4200
	00487-10-00	open back	
	00487-40-00	sew-on settings, open back	
35x9,5	01590-00-00	closed back	4200
	01590-10-00	open back	
	01590-40-00	sew-on settings, open back	
48x13	01589-00-00	closed back	4200
	01589-10-00	open back	
	01589-40-00	sew-on settings, open back	





## Settings with prongs: **Navette**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
23x18 mm

Size	Product code	Type	Swarovski no.
10x8	01619-00-00 01619-10-00 01619-40-00	closed back open back sew-on settings, open back	4224
14x11	01620-00-00 01620-10-00 01620-40-00	closed back open back sew-on settings, open back	4224
23x18	01621-00-00 01621-10-00 01621-40-00	closed back open back sew-on settings, open back	4224
32x17	01546-00-00 01546-10-00 01546-40-00	closed back open back sew-on settings, open back	4227

[< Sitemap](#)



## Settings with prongs: **Navette**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
15x7 mm

Size	Product code	Type	Swarovski no.
5x2,5	01632-00-00 01632-10-00 01632-40-00	closed back open back sew-on settings, open back (2x1)	4228
6x3	01722-00-00 01722-10-00 01722-40-00	closed back open back sew-on settings, open back (2x1)	4228
8x4	00237-00-00 00237-10-00 00237-40-00	closed back open back sew-on settings, open back	4228
10x5	00238-00-00 00238-10-00 00238-40-00	closed back open back sew-on settings, open back	4228
15x7	00394-00-00 00394-10-00 00394-40-00	closed back open back sew-on settings, open back	4228

< [Sitemap](#)



## Settings with prongs: **Navette**

Open search window:  
Ctrl + F



closed back




open back



sew-on settings

The pictures show  
the item in size  
23x15 mm

Size	Product code	Type	Swarovski no.
14x9	01628-00-00	closed back	4230
	01628-10-00	open back	
	01628-40-00	sew-on settings, open back	
19x12	01629-00-00	closed back	4230
	01629-10-00	open back	
	01629-40-00	sew-on settings, open back	
23x15	01630-00-00	closed back	4230
	01630-10-00	open back	
	01630-40-00	sew-on settings, open back	





## Settings with prongs: Pear

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
6x4	01631-00-00	closed back	4320
	01631-10-00	open back	
	01631-40-00	sew-on settings, open back (2x1)	
8x6	01572-00-00	closed back	4320
	01572-10-00	open back	
	01572-40-00	sew-on settings, open back	
10x7	00981-00-00	closed back	4320
	00981-10-00	open back	
	00981-40-00	sew-on settings, open back	
14x10	00251-00-00	closed back	4320
	00251-10-00	open back	
	00251-40-00	sew-on settings, open back	
18x13	00252-00-00	closed back	4320
	00252-10-00	open back	
	00252-40-00	sew-on settings, open back	





## Settings with prongs: Pear

Open search window:  
Ctrl + F



closed back




open back



sew-on settings

The pictures show  
the item in size  
22x11 mm

Size	Product code	Type	Swarovski no.
10x5	01684-00-00	closed back	4322
	01684-10-00	open back	
	01684-40-00	sew-on settings, open back	
14x7	01685-00-00	closed back	4322
	01685-10-00	open back	
	01685-40-00	sew-on settings, open back	
18x9	01686-00-00	closed back	4322
	01686-10-00	open back	
	01686-40-00	sew-on settings, open back	
22x11	01687-00-00	closed back	4322
	01687-10-00	open back	
	01687-40-00	sew-on settings, open back	
30x15	01688-00-00	closed back	4322
	01688-10-00	open back	
	01688-40-00	sew-on settings, open back	





## Settings with prongs: Pear

Open search window:  
Ctrl + F



closed back




open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
30x20	01545-00-00	closed back	 4327
	01545-10-00	open back	
	01545-40-00	sew-on settings, open back	
40x27	01566-00-00	closed back	4327
	01566-10-00	open back	
	01566-40-00	sew-on settings, open back	



closed back




open back



sew-on settings

The pictures show  
the item in size  
13x7,8 mm

Size	Product code	Type	Swarovski no.
6x3,6	00247-00-00	closed back	 4328
	00247-50-00	sew-on settings, closed back (2x1)	
8x4,8	00248-00-00	closed back	4328
	00248-10-00	open back	
	00248-40-00	sew-on settings, open back	
10x6	00249-00-00	closed back	4328
	00249-10-00	open back	
	00249-40-00	sew-on settings, open back	
13x7,8	00250-00-00	closed back	4328
	00250-10-00	open back	
	00250-40-00	sew-on settings, open back	

[< Sitemap](#)





## Settings with prongs: Pear

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
20x5,5 mm

Size	Product code	Type	Swarovski no.
8x7	01719-00-00	closed back	4329
	01719-10-00	open back	
	01719-40-00	sew-on settings, open back	
10x8,7	01720-00-00	closed back	4329
	01720-10-00	open back	
	01720-40-00	sew-on settings, open back	
14x12,1	01721-00-00	closed back	4329
	01721-10-00	open back	
	01721-40-00	sew-on settings, open back	

< [Sitemap](#)



## Settings with prongs: Pear

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
20x5,5 mm


Size	Product code	Type	Swarovski no.
11x3	01626-00-00	closed back	4331
	01626-10-00	open back	
	01626-40-00	sew-on settings, open back	
15x4,2	01637-00-00	closed back	4331
	01637-10-00	open back	
	01637-40-00	sew-on settings, open back	
20x5,5	01638-00-00	closed back	4331
	01638-10-00	open back	
	01638-40-00	sew-on settings, open back	
30x8,3	01639-00-00	closed back	4331
	01639-10-00	open back	
	01639-40-00	sew-on settings, open back	






## Settings with prongs: **Square**


Open search window:  
Ctrl + F



closed back



open back



sew-on settings


The pictures show  
the item in size  
12x12 mm

Size	Product code	Type	Swarovski no.
6x6	00379-00-00 00379-10-00 00379-40-00	closed back open back sew-on settings, open back	4418
8x8	01636-00-00 01636-10-00 01636-40-00	closed back open back sew-on settings, open back	4418
4x4	00468-00-00 00468-10-00 00468-40-00	closed back open back sew-on settings, open back (4x1)	4428
5x5	00264-00-00 00264-10-00 00264-40-00	closed back open back sew-on settings, open back (4x1)	4428
6x6	00379-00-00 00379-10-00 00379-40-00	closed back open back sew-on settings, open back	4428
8x8	00265-00-00 00265-10-00 00265-40-00	closed back open back sew-on settings, open back	4428




## Settings with prongs: **Square**


Open search window:  
Ctrl + F



closed back





open back



sew-on settings

The pictures show  
the item in size  
12x12 mm

Size	Product code	Type	Swarovski no.
6x6	00379-00-00	closed back	4447 
	00379-10-00	open back	
	00379-40-00	sew-on settings, open back	
8x8	00265-00-00	closed back	4447
	00265-10-00	open back	
	00265-40-00	sew-on settings, open back	
10x10	00266-00-00	closed back	4447
	00266-10-00	open back	
	00266-40-00	sew-on settings, open back	
12x12	01540-00-00	closed back	4447
	01540-10-00	open back	
	01540-40-00	sew-on settings, open back	
12x12	01540-00-00	closed back	4481 
	01540-10-00	open back	
	01540-40-00	sew-on settings, open back	
16x16	00363-00-00	closed back	4481
	00363-10-00	open back	
	00363-40-00	sew-on settings, open back	



## Settings with prongs: **Rounded square**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
12x12 mm

Size	Product code	Type	Swarovski no.
10x10	01517-00-00	closed back	4470
	01517-10-00	open back	
	01517-40-00	sew-on settings, open back	
12x12	00268-00-00	closed back	4470
	00268-10-00	open back	
	00268-40-00	sew-on settings, open back	
18x18	00270-00-00	closed back	4470
	00270-10-00	open back	
	00270-40-00	sew-on settings, open back	
Size	Product code	Type	Swarovski no.
8x8	01676-00-00	closed back	4471
	01676-10-00	open back	
	01676-40-00	sew-on settings, open back	
10x10	01677-00-00	closed back	4471
	01677-10-00	open back	
	01677-40-00	sew-on settings, open back	
12x12	00268-00-00	closed back	4471
	00268-10-00	open back	
	00268-40-00	sew-on settings, open back	



## Settings with prongs: **Rounded square**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
14x14 mm

Size	Product code	Type	Swarovski no.
8x8	01676-00-00	closed back	4483
	01676-10-00	open back	
	01676-40-00	sew-on settings, open back	
10x10	01677-00-00	closed back	4483
	01677-10-00	open back	
	01677-40-00	sew-on settings, open back	
12x12	01678-00-00	closed back	4483
	01678-10-00	open back	
	01678-40-00	sew-on settings, open back	
14x14	01679-00-00	closed back	4483
	01679-10-00	open back	
	01679-40-00	sew-on settings, open back	






## Settings with prongs: **Baguette**


Open search window:  
**Ctrl + F**



closed back




open back



sew-on settings

The pictures show  
the item in size  
10x5 mm

Size	Product code	Type	Swarovski no.
6x2	01635-00-00	closed back	4500
	01635-50-00	sew-on settings, closed back	
10x3	00260-00-00	closed back	4500
	00260-50-00	sew-on settings, closed back	
5x2,5	00258-00-00	closed back	4501
	00258-50-00	sew-on settings, closed back (2x1)	
7x3	00259-00-00	closed back	4501
	00259-50-00	sew-on settings, closed back	
10x5	00261-00-00	closed back	4501
	00261-10-00	open back	
	00261-40-00	sew-on settings, open back	





## Settings with prongs: **Baguette**

Open search window:  
**Ctrl + F**



closed back




open back



sew-on settings

The pictures show  
the item in size  
14x8 mm

Size	Product code	Type	Swarovski no.
8x5	01613-00-00	closed back	4505
	01613-10-00	open back	
	01613-40-00	sew-on settings, open back	
10x6	01614-00-00	closed back	4505
	01614-10-00	open back	
	01614-40-00	sew-on settings, open back	
14x8	01615-00-00	closed back	4505
	01615-10-00	open back	
	01615-40-00	sew-on settings, open back	







## Settings with prongs: **Baguette**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
23x11 mm


Size	Product code	Type	Swarovski no.
12x6	01616-00-00 01616-10-00 01616-40-00	closed back open back sew-on settings, open back	4524
16x8	01617-00-00 01617-10-00 01617-40-00	closed back open back sew-on settings, open back	4524
23x11	01618-00-00 01618-10-00 01618-40-00	closed back open back sew-on settings, open back	4524



closed back



open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
8x6	01633-00-00 01633-10-00 01633-40-00	closed back open back sew-on settings, open back	4527
14x10	01549-00-00 01549-10-00 01549-40-00	closed back open back sew-on settings, open back	4527
18x13	01529-00-00 01529-10-00 01529-40-00	closed back open back sew-on settings, open back	4527

[< Sitemap](#)



## Settings with prongs: **Baguette**


Open search window:  
Ctrl + F



closed back




open back



sew-on settings

The pictures show  
the item in size  
24x8 mm

Size	Product code	Type	Swarovski no.
15x5	01525-00-00	closed back	4547
	01525-10-00	open back	
	01525-40-00	sew-on settings, open back	
21x7	01530-00-00	closed back	4547
	01530-10-00	open back	
	01530-40-00	sew-on settings, open back	
24x8	00263-00-00	closed back	4547
	00263-10-00	open back	
	00263-40-00	sew-on settings, open back	
30x10	01538-00-00	closed back	4547
	01538-10-00	open back	
	01538-40-00	sew-on settings, open back	



closed back




open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
14x10	01575-00-00	closed back	4565
	01575-10-00	open back	
	01575-40-00	sew-on settings, open back	
18x13	01576-00-00	closed back	4565
	01576-10-00	open back	
	01576-40-00	sew-on settings, open back	



< [Sitemap](#)




## Settings with prongs: **Octagon**

Open search window:  
Ctrl + F



closed back




open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

Size	Product code	Type	Swarovski no.
6x4	00229-00-00	closed back	4600
	00229-10-00	open back	
	00229-40-00	sew-on settings, open back	
8x6	00231-00-00	closed back	4600
	00231-10-00	open back	
	00231-40-00	sew-on settings, open back	
10x8	00232-00-00	closed back	4600
	00232-10-00	open back	
	00232-40-00	sew-on settings, open back	
12x10	00233-00-00	closed back	4600
	00233-10-00	open back	
	00233-40-00	sew-on settings, open back	
14x10	00234-00-00	closed back	4610
	00234-10-00	open back	
	00234-40-00	sew-on settings, open back	
18x13	01586-00-00	closed back	4610
	01586-10-00	open back	
	01586-40-00	sew-on settings, open back	
20x15	01571-00-00	closed back	4610
	01571-10-00	open back	
	01571-40-00	sew-on settings, open back	





## Settings with prongs: **Octagon**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
18x13 mm

### Size

### Product code

### Type

### Swarovski no.



27x18,5

01526-00-00  
01526-10-00  
01526-40-00

closed back  
open back  
sew-on settings, open back

4627

37x25,5


01567-00-00  
01567-10-00  
01567-40-00

closed back  
open back  
sew-on settings, open back

4627



closed back



open back



sew-on settings

The pictures show  
the item in size  
23 mm

### Size

### Product code

### Type

### Swarovski no.



23 mm

01547-00-00  
01547-10-00  
01547-40-00

closed back  
open back  
sew-on settings, open back

4675

< [Sitemap](#)



## Settings with prongs: **Octagon**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
23 mm


Size	Product code	Type	Swarovski no.
8 mm	01634-00-00	closed back	4678
	01634-10-00	open back	
	01634-40-00	sew-on settings, open back (4x1)	
14 mm	01625-00-00	closed back	4678
	01625-10-00	open back	
	01625-40-00	sew-on settings, open back (4x1)	
23 mm	01624-00-00	closed back	4678
	01624-10-00	open back	
	01624-40-00	sew-on settings, open back (4x1)	






## Settings with prongs: **Octagon**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings


The pictures show  
the item in size  
10 mm

Size	Product code	Type	Swarovski no.
6 mm	01656-00-00	closed back	4480
	01656-10-00	open back	
	01656-40-00	sew-on settings, open back	
8 mm	01657-00-00	closed back	4480
	01657-10-00	open back	
	01657-40-00	sew-on settings, open back	
10 mm	01658-00-00	closed back	4480
	01658-10-00	open back	
	01658-40-00	sew-on settings, open back	
14 mm	01698-00-00	closed back	4480
	01698-10-00	open back	
	01698-40-00	sew-on settings, open back	
18 mm	01699-00-00	closed back	4480
	01699-10-00	open back	
	01699-40-00	sew-on settings, open back	




## Settings with prongs: **Octagon**


Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
14 mm

Size	Product code	Type	Swarovski no.
6 mm	01659-00-00	closed back	4499
	01659-10-00	open back	
	01659-40-00	sew-on settings, open back	
10 mm	01661-00-00	closed back	4499
	01661-10-00	open back	
	01661-40-00	sew-on settings, open back	
14 mm	01662-00-00	closed back	4499
	01662-10-00	open back	
	01662-40-00	sew-on settings, open back	
20 mm	01670-00-00	closed back	4499
	01670-10-00	open back	
	01670-40-00	sew-on settings, open back	

< [Sitemap](#)



## Settings with prongs: Triangle

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
21,5 mm

### Size

### Product code

### Type

### Swarovski no.



15,5 mm

01597-00-00  
01597-10-00  
01597-40-00

closed back  
open back  
sew-on settings, open back

4717

21,5 mm

01598-00-00  
01598-10-00  
01598-40-00

closed back  
open back  
sew-on settings, open back


4717



closed back



open back



sew-on settings

The pictures show  
the item in size  
8 mm

### Size

### Product code

### Type

### Swarovski no.

8 mm

01715-00-00  
01715-10-00  
01715-40-00

closed back  
open back  
sew-on settings, open back

4722



closed back



open back



sew-on settings

The pictures show  
the item in size  
23 mm

### Size

### Product code

### Type

### Swarovski no.



23 mm

01548-00-00  
01548-10-00  
01548-40-00

closed back  
open back  
sew-on settings, open back

4727

[< Sitemap](#)





## Settings with prongs: Heart

Open search window:  
Ctrl + F



closed back




open back



sew-on settings

The pictures show  
the item in sizee  
17x13,5 mm

Size	Product code	Type	Swarovski no.
13x12	01725-00-00 01725-10-00 01725-40-00	closed back open back sew-on settings, open back	 4809
17x13,5	01726-00-00 01726-10-00 01726-40-00	closed back open back sew-on settings, open back	



closed back




open back



sew-on settings

The pictures show  
the item in sizee  
28x28 mm

Size	Product code	Type	Swarovski no.
28x28	01552-00-00 01552-10-00 01552-40-00	closed back open back sew-on settings, open back	 4827



## Settings with prongs: **Heart**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
8,8x8 mm

Size	Product code	Type	Swarovski no.
5,5x5	01705-00-00	closed back	4831
	01705-10-00	open back	
	01705-40-00	sew-on settings, open back	
8,8x8	01706-00-00	closed back	4831
	01706-10-00	open back	
	01706-40-00	sew-on settings, open back	
11x10	01707-00-00	closed back	4831
	01707-10-00	open back	
	01707-40-00	sew-on settings, open back	



< [Sitemap](#)



## Settings with prongs: **FANCY**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
17 mm


Size	Product code	Type	Swarovski no.
6 mm	01651-00-00 01651-10-00 01651-40-00	closed back open back sew-on settings, open back	4485
10,5 mm	01652-00-00 01652-10-00 01652-40-00	closed back open back sew-on settings, open back	4485
17 mm	01653-00-00 01653-10-00 01653-40-00	closed back open back sew-on settings, open back	4485



closed back



open back



sew-on settings

The pictures show  
the item in size  
14x15,8 mm

Size	Product code	Type	Swarovski no.
7,8x8,7	01680-00-00 01680-10-00 01680-40-00	closed back open back sew-on settings, open back	4683
10x11,2	01681-00-00 01681-10-00 01680-40-00	closed back open back sew-on settings, open back	4683
12x13,5	01682-00-00 01682-10-00 01682-40-00	closed back open back sew-on settings, open back	4683
14x15,8	01683-00-00 01683-10-00 01683-40-00	closed back open back sew-on settings, open back	4683

[< Sitemap](#)



## Settings with prongs: **FANCY**


Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
14x16 mm

Size	Product code	Type	Swarovski no.
6x6,9	01663-00-00	closed back	4699
	01663-10-00	open back	
	01663-40-00	sew-on settings, open back	
9,4x10,8	01664-00-00	closed back	4699
	01664-10-00	open back	
	01664-40-00	sew-on settings, open back	
14x16	01665-00-00	closed back	4699
	01665-10-00	open back	
	01665-40-00	sew-on settings, open back	
20x22,9	01671-00-00	closed back	4699
	01671-10-00	open back	
	01671-40-00	sew-on settings, open back	





## Settings with prongs: **FANCY**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
24x15,2 mm


Size	Product code	Type	Swarovski no.
7,8x4,9	01672-00-00	closed back	4707
	01672-10-00	open back	
	01672-40-00	sew-on settings, open back	
13,6x8,6	01673-00-00	closed back	4707
	01673-10-00	open back	
	01673-40-00	sew-on settings, open back	
18,7x11,8	01674-00-00	closed back	4707
	01674-10-00	open back	
	01674-40-00	sew-on settings, open back	
24x15,2	01675-00-00	closed back	4707
	01675-10-00	open back	
	01675-40-00	sew-on settings, open back	






## Settings with prongs: **FANCY**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
26x12 mm


Size	Product code	Type	Swarovski no.
19x9	01599-00-00	closed back	4719
	01599-10-00	open back	
	01599-40-00	sew-on settings, open back	
26x12	01600-00-00	closed back	4719
	01600-10-00	open back	
	01600-40-00	sew-on settings, open back	



closed back



open back



sew-on settings

The pictures show  
the item in size  
23x11,5 mm

Size	Product code	Type	Swarovski no.
10x5	01645-00-00	closed back	4731
	01645-10-00	open back	
	01645-40-00	sew-on settings, open back	
14x7	01647-00-00	closed back	4731
	01647-10-00	open back	
	01647-40-00	sew-on settings, open back	
18x9	01648-00-00	closed back	4731
	01648-10-00	open back	
	01648-40-00	sew-on settings, open back	
23x11,5	01649-00-00	closed back	4731
	01649-10-00	open back	
	01649-40-00	sew-on settings, open back	



[Sitemap](#)




## Settings with prongs: **FANCY**

Open search window:  
**Ctrl + F**



closed back




open back



sew-on settings

The pictures show  
the item in size  
20x16 mm


Size	Product code	Type	Swarovski no.
14x11	01532-00-00 01532-10-00 01532-40-00	closed back open back sew-on settings, open back	 4739
20x16	01531-00-00 01531-10-00 01531-40-00	closed back open back sew-on settings, open back	4739



closed back




open back



sew-on settings

The pictures show  
the item in size  
10 mm

Size	Product code	Type	Swarovski no.
5 mm	01640-00-00 01640-10-00 01640-40-00	closed back open back sew-on settings, open back (3x1)	 4745
10 mm	01641-00-00 01641-10-00 01641-40-00	closed back open back sew-on settings, open back (5x1)	4745

< [Sitemap](#)



## Settings with prongs: **FANCY**

Open search window:  
**Ctrl + F**



closed back



open back



sew-on settings

The pictures show  
the item in size  
19x11,5 mm

Size	Product code	Type	Swarovski no.
14x8,5	01544-00-00	closed back	4757
	01544-10-00	open back	
	01544-40-00	sew-on settings, open back	
19x11,5	01543-00-00	closed back	4757
	01543-10-00	open back	
	01543-40-00	sew-on settings, open back	







## Settings with prongs: **FANCY**

Open search window:  
Ctrl + F



closed back




open back



sew-on settings

The pictures show  
the item in size  
22x12,5 mm

Size	Product code	Type	Swarovski no.
14x8	01583-00-00	closed back	4760
	01583-10-00	open back	
	01583-40-00	sew-on settings, open back	
18x10,5	01584-00-00	closed back	4760
	01584-10-00	open back	
	01584-40-00	sew-on settings, open back	
22x12,5	01585-00-00	closed back	4760
	01585-10-00	open back	
	01585-40-00	sew-on settings, open back	



closed back




open back



sew-on settings

The pictures show  
the item in size  
23x13 mm

Size	Product code	Type	Swarovski no.
18x10	01593-00-00	closed back	4767
	01593-10-00	open back	
	01593-40-00	sew-on settings, open back	
23x13	01594-00-00	closed back	4767
	01594-10-00	open back	
	01594-40-00	sew-on settings, open back	





## Settings with prongs: **FANCY**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
32x13,5 mm

Size	Product code	Type	Swarovski no.
18x7,5	01580-00-00	closed back	4790
	01580-10-00	open back	
	01580-40-00	sew-on settings, open back	
23x10	01581-00-00	closed back	4790
	01581-10-00	open back	
	01581-40-00	sew-on settings, open back	
32x13,5	01582-00-00	closed back	4790
	01582-10-00	open back	
	01582-40-00	sew-on settings, open back	



closed back




open back



sew-on settings

The pictures show  
the item in size  
19 mm

Size	Product code	Type	Swarovski no.
14 mm	01610-00-00	closed back	4795
	01610-10-00	open back	
	01610-40-00	sew-on settings, open back	
19 mm	01609-00-00	closed back	4795
	01609-10-00	open back	
	01609-40-00	sew-on settings, open back	
28 mm	01608-00-00	closed back	4795
	01608-10-00	open back	
	01608-40-00	sew-on settings, open back	



[< Sitemap](#)



## Settings with prongs: **FANCY**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
20x20,4 mm

Size	Product code	Type	Swarovski no.
6x6,1	01666-00-00	closed back	4799
	01666-10-00	open back	
	01666-40-00	sew-on settings, open back	
9,2x9,4	01667-00-00	closed back	4799
	01667-10-00	open back	
	01667-40-00	sew-on settings, open back	
14x14,3	01668-00-00	closed back	4799
	01668-10-00	open back	
	01668-40-00	sew-on settings, open back	
20x20,4	01669-00-00	closed back	4799
	01669-10-00	open back	
	01669-40-00	sew-on settings, open back	





## Settings with prongs: **Fancy**

Open search window:  
Ctrl + F



closed back



open back



sew-on settings

The pictures show  
the item in size  
18 mm

Size	Product code	Type	Swarovski no.
8 mm	01693-00-00	closed back	4460
	01693-10-00	open back	
	01693-40-00	sew-on settings, open back	
10 mm	01694-00-00	closed back	4460
	01694-10-00	open back	
	01694-40-00	sew-on settings, open back	
14 mm	01695-00-00	closed back	4460
	01695-10-00	open back	
	01695-40-00	sew-on settings, open back	
18 mm	01696-00-00	closed back	4460
	01696-10-00	open back	
	01696-40-00	sew-on settings, open back	

