



**Franz
Simm**

Metall- und Druckgusswaren GmbH

Dessestraße 7

D-87600 Kaufbeuren

www.simm-zinkdruckguss.de

www.simm-metallwaren.de

CATALOGUE

Settings with prongs

for SWAROVSKI standard program



Fabrikation
Made in Germany
seit 1955

+49 8341 9668 13-0

info@simm-metallwaren.de



Settings with prongs for SWAROVSKI standard program

Sitemap

- Round

- [SW 1088](#)
- [SW 1122](#)
- [SW 1201](#)
- [SW 1383](#)
- [SW 1401](#)
- [SW 1681](#)
- [SW 1695](#)

- Oval

- [SW 4120](#)
- [SW 4122](#)
- [SW 4127](#)
- [SW 4128](#)
- [SW 4142](#)
- [SW 4160](#)
- [SW 4161](#)
- [SW 4162](#)
- [SW 4196](#)

- Navette

- [SW 4200](#)
- [SW 4224](#)
- [SW 4227](#)
- [SW 4228](#)
- [SW 4230](#)

- Pear

- [SW 4320](#)
- [SW 4322](#)
- [SW 4327](#)
- [SW 4328](#)
- [SW 4329](#)
- [SW 4331](#)

- Square

- [SW 4418](#)
- [SW 4428](#)
- [SW 4447](#)
- [SW 4480](#)
- [SW 4481](#)
- [SW 4499](#)

- Rounded square

- [SW 4470](#)
- [SW 4471](#)
- [SW 4483](#)
- [SW 4487](#)

- Baguette

- [SW 4500](#)
- [SW 4501](#)
- [SW 4505](#)
- [SW 4524](#)
- [SW 4527](#)
- [SW 4547](#)
- [SW 4565](#)

- Octagon

- [SW 4600](#)
- [SW 4610](#)
- [SW 4627](#)
- [SW 4675](#)
- [SW 4678](#)
- [SW 4480](#)
- [SW 4499](#)

- Triangle

- [SW 4706](#)
- [SW 4717](#)
- [SW 4722](#)
- [SW 4727](#)

- Heart

- [SW 4809](#)
- [SW 4815](#)
- [SW 4827](#)
- [SW 4831](#)

- Fancy

- [SW 4460](#)
- [SW 4485](#)
- [SW 4683](#)
- [SW 4699](#)
- [SW 4707](#)
- [SW 4719](#)
- [SW 4731](#)
- [SW 4739](#)
- [SW 4745](#)
- [SW 4757](#)
- [SW 4760](#)
- [SW 4767](#)
- [SW 4790](#)
- [SW 4795](#)
- [SW 4799](#)

- Round

- [SW 2006](#)
- [SW 2028](#)
- [SW 2035](#)
- [SW 2058](#)
- [SW 2072](#)
- [SW 2090/4](#)

- Oval

- [SW 2190/4](#)

- Square

- [SW 2415](#)
- [SW 2483](#)
- [SW 2493](#)

- Baguette

- [SW 2520](#)
- [SW 4581/82/83/84](#)

- Triangel

- [SW 4842](#)

- Rhomb

- [SW 2709](#)

- Fancy

- [SW 4756](#)
- [SW 4759](#)
- [SW 4766](#)
- [SW 4787](#)

**Material:**

Tombak MS 85 ÖkoTe/ 100 Standard

Minimum quantity:

raw: 500 Pieces

plated: 1 KG

Search option:

Please press „CTRL + F“ to open the search window.

REACH REGULATION

We confirm that our raw-material does not contain any of the substances of high concern (SVHC) and all our products are conform to the REACH regulation.

CHEMICAL-COMPOSITION Tombac (alloy: CuZn15)

	Einheit	Min.	Sollwert Ma/.	Istwert Ma/.
CU Kupfergehalt	%	84	86	84,572
FE Eisengehalt	%		0,05	0,0042
PB Bleigehalt	%		0,05	0,0162
NI Nickelgehalt	%		0,2	0,0115
SN Zinngehalt	%		0,05	0,0327
ZN Zinkgehalt	%		Rest	
AL Aluminiumgehalt	%		0,02	0,0005
SI Siliziumgehalt	%			0,0005




Settings with prongs: **Round**

Open search window:
Ctrl + F



closed back



sew-on settings

The pictures show
the item in size
m/ss40

Size	Product code	Type	Swarovski no.
m/ss6	01150-00-00	closed back	1088
m/ss8	00200-00-00	closed back	1088
m/ss10	00202-00-00	closed back	1088
m/ss12	00204-00-00	closed back	1088
m/ss15	00205-00-00	closed back	1088
m/ss19	00207-00-00	closed back	1088
m/ss22	00208-00-00	closed back	1088
m/ss25	00209-00-00	closed back	1088
m/ss30	00210-00-00	closed back	1088
m/ss35	01703-00-00	closed back	1088
	01703-50-00	sew-on settings, closed back	
m/ss40	01702-00-00	closed back	1088
	01702-50-00	sew-on settings, closed back	



Settings with prongs: **Round**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
ss48

Size	Product code	Type	Swarovski no.
			
ss12	00211-00-00 00211-10-00 00211-40-00	closed back open back sew-on settings, open back (4x1)	1088
ss15	00212-00-00 00212-10-00 00212-40-00	closed back open back sew-on settings, open back (4x1)	1088
pp32	01689-00-00 01689-10-00 01689-40-00	closed back open back sew-on settings, open back (4x1)	1088
ss18	00206-00-00 00206-10-00 00206-40-00	closed back open back sew-on settings, open back (4x1)	1088
ss19	00213-00-00 00213-10-00 00213-40-00	closed back open back sew-on settings, open back (4x1)	1088
ss25	00214-00-00 00214-10-00 00214-40-00	closed back open back sew-on settings, open back (4x1)	1088
ss30	00215-00-00 00215-10-00 00215-40-00	closed back open back sew-on settings, open back	1088
ss35	00216-00-00 00216-10-00 00216-40-00	closed back open back sew-on settings, open back	1088
ss40	00217-00-00 00217-10-00 00217-40-00	closed back open back sew-on settings, open back	1088
ss45	00218-00-00 00218-10-00 00218-40-00	closed back open back sew-on settings, open back	1088

< [Sitemap](#)



Settings with prongs: **Round**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
ss48

Size	Product code	Type	Swarovski no.
			
ss47	01574-00-00	closed back	1088
	01574-10-00	open back	
	01574-40-00	sew-on settings, open back	
ss48	00333-00-00	closed back	1088
	00333-10-00	open back	
	00333-40-00	sew-on settings, open back	
ss50	00219-00-00	closed back	1088
	00219-10-00	open back	
	00219-40-00	sew-on settings, open back	

< [Sitemap](#)



Settings with prongs: **Round RIVOLI**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
14 mm

Size	Product code	Type	Swarovski no.
			
ss40	01602-00-00	closed back	1122
	01602-10-00	open back	
	01602-40-00	sew-on settings, open back	
ss47	01579-00-00	closed back	1122
	01579-10-00	open back	
	01579-40-00	sew-on settings, open back	
10 mm	01704-00-00	closed back	1122
	01704-10-00	open back	
	01704-40-00	sew-on settings, open back	
12 mm	01361-00-00	closed back	1122
	01361-10-00	open back	
	01361-40-00	sew-on settings, open back	
14 mm	01360-00-00	closed back	1122
	01360-10-00	open back	
	01360-40-00	sew-on settings, open back	
16 mm	01359-00-00	closed back	1122
	01359-10-00	open back	
	01359-40-00	sew-on settings, open back	
18 mm	01357-00-00	closed back	1122
	01357-10-00	open back	
	01357-40-00	sew-on settings, open back	



Settings with prongs: **Round**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
27 mm

Size	Product code	Type	Swarovski no.
27 mm	01550-00-00	closed back	1201
	01550-10-00	open back	
	01550-40-00	sew-on settings, open back	
35 mm	01573-00-00	closed back	1201
	01573-10-00	open back	
	01573-40-00	sew-on settings, open back	



closed back



open back



sew-on settings

The pictures show
the item in size
14 mm

Size	Product code	Type	Swarovski no.
8 mm	01634-00-00	closed back	1383
	01634-10-00	open back	
	01634-40-00	sew-on settings, open back	
10 mm	01723-00-00	closed back	1383
	01723-10-00	open back	
	01723-40-00	sew-on settings, open back	
14 mm	01625-00-00	closed back	1383
	01625-10-00	open back	
	01625-40-00	sew-on settings, open back	

< [Sitemap](#)



Settings with prongs: **Round**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
11,8 mm

Size	Product code	Type	Swarovski no.
8 mm	01712-00-00	closed back	1401
	01712-10-00	open back	
	01712-40-00	sew-on settings, open back	
10 mm	00218-00-00	closed back	1401
	00218-10-00	open back	
	00218-40-00	sew-on settings, open back	
11,8 mm	00219-00-00	closed back	1401
	00219-10-00	open back	
	00219-40-00	sew-on settings, open back	



Settings with prongs: **Round**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
14 mm

Size	Product code	Type	Swarovski no.
			  
12 mm	01361-00-00 01361-10-00 01361-40-00	closed back open back sew-on settings, open back	1681
16 mm	01359-00-00 01359-10-00 01359-40-00	closed back open back sew-on settings, open back	1681
			  
10 mm	01574-00-00 01574-10-00 01574-40-00	closed back open back sew-on settings, open back	1695
14 mm	01360-00-00 01360-10-00 01360-40-00	closed back open back sew-on settings, open back	1695



Settings with prongs: **OVAL**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
			
6/4	01537-00-00	closed back	4120
	01537-10-00	open back	
	01537-40-00	sew-on settings, open back (2x1)	
8/6	00221-00-00	closed back	4120
	00221-10-00	open back	
	00221-40-00	sew-on settings, open back	
14/10	00225-00-00	closed back	4120
	00225-10-00	open back	
	00225-40-00	sew-on settings, open back	
18/13	00226-00-00	closed back	4120
	00226-10-00	open back	
	00226-40-00	sew-on settings, open back	
25/18	01046-00-00	closed back	4120
	01046-10-00	open back	
	01046-40-00	sew-on settings, open back	
			
8/6	01642-00-00	closed back	4122
	01642-10-00	open back	
	01642-40-00	sew-on settings, open back	
14/10,5	01643-00-00	closed back	4122
	01643-10-00	open back	
	01643-40-00	sew-on settings, open back	
18/13,5	01644-00-00	closed back	4122
	01644-10-00	open back	
	01644-40-00	sew-on settings, open back	



Settings with prongs: **OVAL**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
30/22	01539-00-00 01539-10-00 01539-40-00	closed back open back sew-on settings, open back	4127
39/28	01565-00-00 01565-10-00 01565-40-00	closed back open back sew-on settings, open back	4127
6/4	01537-00-00 01537-10-00 01537-40-00	closed back open back sew-on settings, open back (2x1)	4128
8/6	00221-00-00 00221-10-00 00221-40-00	closed back open back sew-on settings, open back	4128
10/8	00222-00-00 00222-10-00 00222-40-00	closed back open back sew-on settings, open back	4128
14/10	00225-00-00 00225-10-00 00225-40-00	closed back open back sew-on settings, open back	4128



Settings with prongs: **OVAL**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
10/8	00222-00-00 00222-10-00 00222-40-00	closed back open back sew-on settings, open back	4142
14/11	01654-00-00 01654-10-00 01654-40-00	closed back open back sew-on settings, open back	4142
18/14	01655-00-00 01655-10-00 01655-40-00	closed back open back sew-on settings, open back	4142



Settings with prongs: **OVAL**

Open search window:
Ctrl + F



closed back




open back



sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
			
8/6	01708-00-00	closed back	4160
	01708-10-00	open back	
	01708-40-00	sew-on settings, open back	
10/8	01709-00-00	closed back	4160
	01709-10-00	open back	
	01709-40-00	sew-on settings, open back	
14/10	01710-00-00	closed back	4160
	01710-10-00	open back	
	01710-40-00	sew-on settings, open back	
18/13	01711-00-00	closed back	4160
	01711-10-00	open back	
	01711-40-00	sew-on settings, open back	



Settings with prongs: **OVAL**

Open search window:
Ctrl + F



closed back




open back



sew-on settings

The pictures show
the item in size
27/9 mm

Size	Product code	Type	Swarovski no.
			
15/5	00227-00-00 00227-10-00 00227-40-00	closed back open back sew-on settings, open back	4161
21/7	01541-00-00 01541-10-00 01541-40-00	closed back open back sew-on settings, open back	4161
27/9	00228-00-00 00228-10-00 00228-40-00	closed back open back sew-on settings, open back	4161



closed back




open back



sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
			
10/5,5	01690-00-00 01690-10-00 01690-40-00	closed back open back sew-on settings, open back	4162
14/7,5	01691-00-00 01691-10-00 01691-40-00	closed back open back sew-on settings, open back	4162
18/9,5	01692-00-00 01692-10-00 01692-40-00	closed back open back sew-on settings, open back	4162

< [Sitemap](#)



Settings with prongs: **OVAL**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
			  
23/20	01592-00-00 01592-10-00 01592-40-00	closed back open back sew-on settings, open back	4196
30/26	01591-00-00 01591-10-00 01591-40-00	closed back open back sew-on settings, open back	4196



Settings with prongs: **Navette**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
35/9,5

Size	Product code	Type	Swarovski no.
11/3	00392-00-00	closed back	4200
	00392-50-00	sew-on settings, closed back	
15/4	00487-00-00	closed back	4200
	00487-10-00	open back	
	00487-40-00	sew-on settings, open back	
35/9,5	01590-00-00	closed back	4200
	01590-10-00	open back	
	01590-40-00	sew-on settings, open back	
48/13	01589-00-00	closed back	4200
	01589-10-00	open back	
	01589-40-00	sew-on settings, open back	



Settings with prongs: **Navette**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
23/18 mm

Size	Product code	Type	Swarovski no.
10/8	01619-00-00 01619-10-00 01619-40-00	closed back open back sew-on settings, open back	4224
14/11	01620-00-00 01620-10-00 01620-40-00	closed back open back sew-on settings, open back	4224
23/18	01621-00-00 01621-10-00 01621-40-00	closed back open back sew-on settings, open back	4224
32/17	01546-00-00 01546-10-00 01546-40-00	closed back open back sew-on settings, open back	4227



Settings with prongs: **Navette**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
15/7 mm

Size	Product code	Type	Swarovski no.
			
5/2,5	01632-00-00	closed back	4228
	01632-10-00	open back	
	01632-40-00	sew-on settings, open back (2x1)	
6/3	01722-00-00	closed back	4228
	01722-10-00	open back	
	01722-40-00	sew-on settings, open back (2x1)	
8/4	00237-00-00	closed back	4228
	00237-10-00	open back	
	00237-40-00	sew-on settings, open back	
10/5	00238-00-00	closed back	4228
	00238-10-00	open back	
	00238-40-00	sew-on settings, open back	
15/7	00394-00-00	closed back	4228
	00394-10-00	open back	
	00394-40-00	sew-on settings, open back	

< [Sitemap](#)



Settings with prongs: **Navette**

Open search window:
Ctrl + F



closed back




open back



sew-on settings

The pictures show
the item in size
23/15 mm

Size	Product code	Type	Swarovski no.
			
14/9	01628-00-00	closed back	4230
	01628-10-00	open back	
	01628-40-00	sew-on settings, open back	
19/12	01629-00-00	closed back	4230
	01629-10-00	open back	
	01629-40-00	sew-on settings, open back	
23/15	01630-00-00	closed back	4230
	01630-10-00	open back	
	01630-40-00	sew-on settings, open back	



Settings with prongs: **Pear**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
			
6/4	01631-00-00	closed back	4320
	01631-10-00	open back	
	01631-40-00	sew-on settings, open back (2x1)	
8/6	01572-00-00	closed back	4320
	01572-10-00	open back	
	01572-40-00	sew-on settings, open back	
10/7	00981-00-00	closed back	4320
	00981-10-00	open back	
	00981-40-00	sew-on settings, open back	
14/10	00251-00-00	closed back	4320
	00251-10-00	open back	
	00251-40-00	sew-on settings, open back	
18/13	00252-00-00	closed back	4320
	00252-10-00	open back	
	00252-40-00	sew-on settings, open back	



Settings with prongs: **Pear**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
22x11 mm

Size	Product code	Type	Swarovski no.
10/5	01684-00-00	closed back	4322
	01684-10-00	open back	
	01684-40-00	sew-on settings, open back	
14/7	01685-00-00	closed back	4322
	01685-10-00	open back	
	01685-40-00	sew-on settings, open back	
18/9	01686-00-00	closed back	4322
	01686-10-00	open back	
	01686-40-00	sew-on settings, open back	
22/11	01687-00-00	closed back	4322
	01687-10-00	open back	
	01687-40-00	sew-on settings, open back	
30/15	01688-00-00	closed back	4322
	01688-10-00	open back	
	01688-40-00	sew-on settings, open back	

[Sitemap](#)



Settings with prongs: **Pear**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
18/13 m


Size	Product code	Type	Swarovski no.
30/20	01545-00-00	closed back	4327
	01545-10-00	open back	
	01545-40-00	sew-on settings, open back	
40/27	01566-00-00	closed back	4327
	01566-10-00	open back	
	01566-40-00	sew-on settings, open back	



closed back



open back



sew-on settings

The pictures show
the item in size
13/7,8 mm

Size	Product code	Type	Swarovski no.
6/3,6	00247-00-00	closed back	4328
	00247-50-00	sew-on settings, closed back (2x1)	
8/4,8	00248-00-00	closed back	4328
	00248-10-00	open back	
	00248-40-00	sew-on settings, open back	
10/6	00249-00-00	closed back	4328
	00249-10-00	open back	
	00249-40-00	sew-on settings, open back	
13/7,8	00250-00-00	closed back	4328
	00250-10-00	open back	
	00250-40-00	sew-on settings, open back	





Settings with prongs: **Pear**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
20/5,5 mm

Size	Product code	Type	Swarovski no.
8/7	01719-00-00	closed back	4329
	01719-10-00	open back	
	01719-40-00	sew-on settings, open back	
10/8,7	01720-00-00	closed back	4329
	01720-10-00	open back	
	01720-40-00	sew-on settings, open back	
14/12,1	01721-00-00	closed back	4329
	01721-10-00	open back	
	01721-40-00	sew-on settings, open back	

[Sitemap](#)



Settings with prongs: **Pear**


Open search window:
Ctrl + F



closed back




open back



sew-on settings


The pictures show
the item in size
20/5,5 mm

Size	Product code	Type	Swarovski no.
			
11/3	01626-00-00	closed back	4331
	01626-10-00	open back	
	01626-40-00	sew-on settings, open back	
15/4,2	01637-00-00	closed back	4331
	01637-10-00	open back	
	01637-40-00	sew-on settings, open back	
20/5,5	01638-00-00	closed back	4331
	01638-10-00	open back	
	01638-40-00	sew-on settings, open back	
30/8,3	01639-00-00	closed back	4331
	01639-10-00	open back	
	01639-40-00	sew-on settings, open back	




Settings with prongs: **Square**


Open search window:
Ctrl + F



closed back



open back



sew-on settings


The pictures show
the item in size
12x12 mm

Size	Product code	Type	Swarovski no.
			
6/6	00379-00-00 00379-10-00 00379-40-00	closed back open back sew-on settings, open back	4418
8/8	01636-00-00 01636-10-00 01636-40-00	closed back open back sew-on settings, open back	4418
			
4/4	00468-00-00 00468-10-00 00468-40-00	closed back open back sew-on settings, open back (4x1)	4428
5/5	00264-00-00 00264-10-00 00264-40-00	closed back open back sew-on settings, open back (4x1)	4428
6/6	00379-00-00 00379-10-00 00379-40-00	closed back open back sew-on settings, open back	4428
8/8	00265-00-00 00265-10-00 00265-40-00	closed back open back sew-on settings, open back	4428




Settings with prongs: **Square**


Open search window:
Ctrl + F



closed back



open back



sew-on settings


The pictures show
the item in size
12x12 mm

Size	Product code	Type	Swarovski no.
			  
6/6	00379-00-00	closed back	4447
	00379-10-00	open back	
	00379-40-00	sew-on settings, open back	
8/8	00265-00-00	closed back	4447
	00265-10-00	open back	
	00265-40-00	sew-on settings, open back	
10/10	00266-00-00	closed back	4447
	00266-10-00	open back	
	00266-40-00	sew-on settings, open back	
12/12	01540-00-00	closed back	4447
	01540-10-00	open back	
	01540-40-00	sew-on settings, open back	
			  
12/12	01540-00-00	closed back	4481
	01540-10-00	open back	
	01540-40-00	sew-on settings, open back	
16/16	00363-00-00	closed back	4481
	00363-10-00	open back	
	00363-40-00	sew-on settings, open back	




Settings with prongs: **Square**

Open search window:
Ctrl + F



closed back



open back



sew-on settings


The pictures show
the item in size
10 mm

Size	Product code	Type	Swarovski no.
			  
6 mm	01656-00-00	closed back	4480
	01656-10-00	open back	
	01656-40-00	sew-on settings, open back	
8 mm	01657-00-00	closed back	4480
	01657-10-00	open back	
	01657-40-00	sew-on settings, open back	
10 mm	01658-00-00	closed back	4480
	01658-10-00	open back	
	01658-40-00	sew-on settings, open back	
14 mm	01698-00-00	closed back	4480
	01698-10-00	open back	
	01698-40-00	sew-on settings, open back	
18 mm	01699-00-00	closed back	4480
	01699-10-00	open back	
	01699-40-00	sew-on settings, open back	




Settings with prongs: **Square**


Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
14 mm

Size	Product code	Type	Swarovski no.
			
6 mm	01659-00-00	closed back	4499
	01659-10-00	open back	
	01659-40-00	sew-on settings, open back	
10 mm	01661-00-00	closed back	4499
	01661-10-00	open back	
	01661-40-00	sew-on settings, open back	
14 mm	01662-00-00	closed back	4499
	01662-10-00	open back	
	01662-40-00	sew-on settings, open back	
20 mm	01670-00-00	closed back	4499
	01670-10-00	open back	
	01670-40-00	sew-on settings, open back	

[Sitemap](#)



Settings with prongs: **Rounded square**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
12x12 mm

Size	Product code	Type	Swarovski no.
			  
10/10	01517-00-00	closed back	4470
	01517-10-00	open back	
	01517-40-00	sew-on settings, open back	
12/12	00268-00-00	closed back	4470
	00268-10-00	open back	
	00268-40-00	sew-on settings, open back	
18/18	00270-00-00	closed back	4470
	00270-10-00	open back	
	00270-40-00	sew-on settings, open back	

Size	Product code	Type	Swarovski no.
8/8	01676-00-00	closed back	4471
	01676-10-00	open back	
	01676-40-00	sew-on settings, open back	
10/10	01677-00-00	closed back	4471
	01677-10-00	open back	
	01677-40-00	sew-on settings, open back	
12/12	00268-00-00	closed back	4471
	00268-10-00	open back	
	00268-40-00	sew-on settings, open back	

< [Sitemap](#)



Settings with prongs: **Rounded square**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
14x14 mm

Size	Product code	Type	Swarovski no.
			
8/8	01676-00-00	closed back	4483
	01676-10-00	open back	
	01676-40-00	sew-on settings, open back	
10/10	01677-00-00	closed back	4483
	01677-10-00	open back	
	01677-40-00	sew-on settings, open back	
12/12	01678-00-00	closed back	4483
	01678-10-00	open back	
	01678-40-00	sew-on settings, open back	
14/14	01679-00-00	closed back	4483
	01679-10-00	open back	
	01679-40-00	sew-on settings, open back	
Size	Product code	Type	Swarovski no.
27/27	01729-00-00	closed back	4487
	01729-10-00	open back	
	01729-40-00	sew-on settings, open back	




Settings with prongs: **Baguette**


Open search window:
Ctrl + F



closed back





open back



sew-on settings

The pictures show
the item in size
10/5 mm

Size	Product code	Type	Swarovski no.
			
6/2	01635-00-00 01635-50-00	closed back sew-on settings, closed back	4500
10/3	00260-00-00 00260-50-00	closed back sew-on settings, closed back	4500
			
5/2,5	00258-00-00 00258-50-00	closed back sew-on settings, closed back (2x1)	4501
7/3	00259-00-00 00259-50-00	closed back sew-on settings, closed back	4501
10/5	00261-00-00 00261-10-00 00261-40-00	closed back open back sew-on settings, open back	4501



Settings with prongs: **Baguette**

Open search window:
Ctrl + F



closed back




open back



sew-on settings

The pictures show
the item in size
14/8 mm

Size	Product code	Type	Swarovski no.
8/5	01613-00-00	closed back	4505
	01613-10-00	open back	
	01613-40-00	sew-on settings, open back	
10/6	01614-00-00	closed back	4505
	01614-10-00	open back	
	01614-40-00	sew-on settings, open back	
14/8	01615-00-00	closed back	4505
	01615-10-00	open back	
	01615-40-00	sew-on settings, open back	





Settings with prongs: **Baguette**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
23/11 mm

Size	Product code	Type	Swarovski no.
12/6	01616-00-00 01616-10-00 01616-40-00	closed back open back sew-on settings, open back	4524
16/8	01617-00-00 01617-10-00 01617-40-00	closed back open back sew-on settings, open back	4524
23/11	01618-00-00 01618-10-00 01618-40-00	closed back open back sew-on settings, open back	4524



closed back



open back



sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
8/6	01633-00-00 01633-10-00 01633-40-00	closed back open back sew-on settings, open back	4527
14/10	01549-00-00 01549-10-00 01549-40-00	closed back open back sew-on settings, open back	4527
18/13	01529-00-00 01529-10-00 01529-40-00	closed back open back sew-on settings, open back	4527

< [Sitemap](#)



Settings with prongs: **Baguette**

Open search window:
Ctrl + F



closed back




open back



sew-on settings

The pictures show
the item in size
24/8 mm

Size	Product code	Type	Swarovski no.
15/5	01525-00-00	closed back	4547
	01525-10-00	open back	
	01525-40-00	sew-on settings, open back	
21/7	01530-00-00	closed back	4547
	01530-10-00	open back	
	01530-40-00	sew-on settings, open back	
24/8	00263-00-00	closed back	4547
	00263-10-00	open back	
	00263-40-00	sew-on settings, open back	
30/10	01538-00-00	closed back	4547
	01538-10-00	open back	
	01538-40-00	sew-on settings, open back	



closed back



open back



sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
14/10	01575-00-00	closed back	4565
	01575-10-00	open back	
	01575-40-00	sew-on settings, open back	
18/13	01576-00-00	closed back	4565
	01576-10-00	open back	
	01576-40-00	sew-on settings, open back	



< [Sitemap](#)



Settings with prongs: **Octagon**

Open search window:
Ctrl + F



closed back




open back



sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
			
6/4	00229-00-00	closed back	4600
	00229-10-00	open back	
	00229-40-00	sew-on settings, open back	
8/6	00231-00-00	closed back	4600
	00231-10-00	open back	
	00231-40-00	sew-on settings, open back	
10/8	00232-00-00	closed back	4600
	00232-10-00	open back	
	00232-40-00	sew-on settings, open back	
12/10	00233-00-00	closed back	4600
	00233-10-00	open back	
	00233-40-00	sew-on settings, open back	
			
14/10	00234-00-00	closed back	4610
	00234-10-00	open back	
	00234-40-00	sew-on settings, open back	
18/13	01586-00-00	closed back	4610
	01586-10-00	open back	
	01586-40-00	sew-on settings, open back	
20/15	01571-00-00	closed back	4610
	01571-10-00	open back	
	01571-40-00	sew-on settings, open back	




Settings with prongs: **Octagon**

Open search window:
Ctrl + F



closed back



open back




sew-on settings

The pictures show
the item in size
18/13 mm

Size	Product code	Type	Swarovski no.
27/18,5	01526-00-00 01526-10-00 01526-40-00	closed back open back sew-on settings, open back	   4627
37/25,5	01567-00-00 01567-10-00 01567-40-00	closed back open back sew-on settings, open back	4627



closed back



open back



sew-on settings

The pictures show
the item in size
23 mm

Size	Product code	Type	Swarovski no.
23 mm	01547-00-00 01547-10-00 01547-40-00	closed back open back sew-on settings, open back	   4675



Settings with prongs: **Octagon**

Open search window:
Ctrl + F



closed back



open back



sew-on settings


The pictures show
the item in size
23 mm

Size	Product code	Type	Swarovski no.
			  
8 mm	01634-00-00	closed back	4678
	01634-10-00	open back	
	01634-40-00	sew-on settings, open back (4x1)	
14 mm	01625-00-00	closed back	4678
	01625-10-00	open back	
	01625-40-00	sew-on settings, open back (4x1)	
23 mm	01624-00-00	closed back	4678
	01624-10-00	open back	
	01624-40-00	sew-on settings, open back (4x1)	




Settings with prongs: **Octagon**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
10 mm


Size	Product code	Type	Swarovski no.
			  
6 mm	01656-00-00	closed back	4480
	01656-10-00	open back	
	01656-40-00	sew-on settings, open back	
8 mm	01657-00-00	closed back	4480
	01657-10-00	open back	
	01657-40-00	sew-on settings, open back	
10 mm	01658-00-00	closed back	4480
	01658-10-00	open back	
	01658-40-00	sew-on settings, open back	
14 mm	01698-00-00	closed back	4480
	01698-10-00	open back	
	01698-40-00	sew-on settings, open back	
18 mm	01699-00-00	closed back	4480
	01699-10-00	open back	
	01699-40-00	sew-on settings, open back	

< [Sitemap](#)




Settings with prongs: **Octagon**


Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
14 mm

Size	Product code	Type	Swarovski no.
			  
6 mm	01659-00-00	closed back	4499
	01659-10-00	open back	
	01659-40-00	sew-on settings, open back	
10 mm	01661-00-00	closed back	4499
	01661-10-00	open back	
	01661-40-00	sew-on settings, open back	
14 mm	01662-00-00	closed back	4499
	01662-10-00	open back	
	01662-40-00	sew-on settings, open back	
20 mm	01670-00-00	closed back	4499
	01670-10-00	open back	
	01670-40-00	sew-on settings, open back	

< [Sitemap](#)



Settings with prongs: **Triangle**

Open search window:
Ctrl + F



Boden



Loch



AK4L

The pictures show
the item in size
12 mm

Size	Product code	Type	Swarovski no.
8 mm	01717-00-00	closed back	4706
	01717-10-00	open back	
	01717-40-00	sew-on settings, open back	
12 mm	01718-00-00	closed back	4706
	01718-10-00	open back	
	01718-40-00	sew-on settings, open back	



closed back



open back



sew-on settings

The pictures show
the item in size
21,5 mm

Size	Product code	Type	Swarovski no.
15,5 mm	01597-00-00	closed back	4717
	01597-10-00	open back	
	01597-40-00	sew-on settings, open back	
21,5 mm	01598-00-00	closed back	4717
	01598-10-00	open back	
	01598-40-00	sew-on settings, open back	





Settings with prongs: **Triangle**

Open search window:
Ctrl + F



mit Boden

Size

8 mm



ohne Boden

Product code

01715-00-00
01715-10-00
01715-40-00



Aufnähkessel

Type

closed back
open back
sew-on settings, open back

The pictures show
the item in size
8 mm

Swarovski no.

4722



mit Boden

Size

23 mm



ohne Boden

Product code

01548-00-00
01548-10-00
01548-40-00



Aufnähkessel

Type

closed back
open back
sew-on settings, open back

The pictures show
the item in size
23 mm

Swarovski no.



4727



Settings with prongs: **Heart**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in sizee
17/13,5 mm

Size	Product code	Type	Swarovski no.
8/7,5	01728-00-00	closed back	4809
	01728-10-00	open back	
	01728-40-00	sew-on settings, open back	
13/12	01725-00-00	closed back	4809
	01725-10-00	open back	
	01725-40-00	sew-on settings, open back	
17/15,5	01726-00-00	closed back	4809
	01726-10-00	open back	
	01726-40-00	sew-on settings, open back	



closed back



open back



sew-on settings

he pictures show
the item in sizee
10/8 mm

Size	Product code	Type	Swarovski no.
10/8	01730-00-00	closed back	4815
	01730-10-00	open back	
	01730-40-00	sew-on settings, open back	



Settings with prongs: **Heart**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in sizee
28/28 mm

Size

Product code

Type

Swarovski no.



28/28

01552-00-00
01552-10-00
01552-40-00

closed back
open back
sew-on settings, open back

4827



closed back



open back



sew-on settings

The pictures show
the item in sizee
8,8/8 mm

Size

Product code

Type

Swarovski no.



5,5/5

01705-00-00
01705-10-00
01705-40-00

closed back
open back
sew-on settings, open back

4831

8,8/8

01706-00-00
01706-10-00
01706-40-00

closed back
open back
sew-on settings, open back

4831

11/10

01707-00-00
01707-10-00
01707-40-00

closed back
open back
sew-on settings, open back

4831



Settings with prongs: **FANCY**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
17 mm


Size	Product code	Type	Swarovski no.
			
6 mm	01651-00-00 01651-10-00 01651-40-00	closed back open back sew-on settings, open back	4485
10,5 mm	01652-00-00 01652-10-00 01652-40-00	closed back open back sew-on settings, open back	4485
17 mm	01653-00-00 01653-10-00 01653-40-00	closed back open back sew-on settings, open back	4485



closed back



open back



sew-on settings

The pictures show
the item in size
14x15,8 mm

Size	Product code	Type	Swarovski no.
			
7,8/8,7	01680-00-00 01680-10-00 01680-40-00	closed back open back sew-on settings, open back	4683
10/11,2	01681-00-00 01681-10-00 01680-40-00	closed back open back sew-on settings, open back	4683
12/13,5	01682-00-00 01682-10-00 01682-40-00	closed back open back sew-on settings, open back	4683
14/15,8	01683-00-00 01683-10-00 01683-40-00	closed back open back sew-on settings, open back	4683

[◀ Sitemap](#)



Settings with prongs: **FANCY**


Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
14x16 mm

Size	Product code	Type	Swarovski no.
6/6,9	01663-00-00	closed back	4699
	01663-10-00	open back	
	01663-40-00	sew-on settings, open back	
9,4/10,8	01664-00-00	closed back	4699
	01664-10-00	open back	
	01664-40-00	sew-on settings, open back	
14/16	01665-00-00	closed back	4699
	01665-10-00	open back	
	01665-40-00	sew-on settings, open back	
20/22,9	01671-00-00	closed back	4699
	01671-10-00	open back	
	01671-40-00	sew-on settings, open back	

< [Sitemap](#)



Settings with prongs: **FANCY**

Open search window:
Ctrl + F



closed back




open back



sew-on settings


The pictures show
the item in size
24x15,2 mm

Size	Product code	Type	Swarovski no.
			
7,8/4,9	01672-00-00 01672-10-00 01672-40-00	closed back open back sew-on settings, open back	4707
13,6/8,6	01673-00-00 01673-10-00 01673-40-00	closed back open back sew-on settings, open back	4707
18,7/11,8	01674-00-00 01674-10-00 01674-40-00	closed back open back sew-on settings, open back	4707
24/15,2	01675-00-00 01675-10-00 01675-40-00	closed back open back sew-on settings, open back	4707




Settings with prongs: **FANCY**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
26/12 mm

Size	Product code	Type	Swarovski no.
19/9	01599-00-00	closed back	4719
	01599-10-00	open back	
	01599-40-00	sew-on settings, open back	
26/12	01600-00-00	closed back	4719
	01600-10-00	open back	
	01600-40-00	sew-on settings, open back	



closed back



open back



sew-on settings

The pictures show
the item in size
23/11,5 mm

Size	Product code	Type	Swarovski no.
10/5	01645-00-00	closed back	4731
	01645-10-00	open back	
	01645-40-00	sew-on settings, open back	
14/7	01647-00-00	closed back	4731
	01647-10-00	open back	
	01647-40-00	sew-on settings, open back	
18/9	01648-00-00	closed back	4731
	01648-10-00	open back	
	01648-40-00	sew-on settings, open back	
23/11,5	01649-00-00	closed back	4731
	01649-10-00	open back	
	01649-40-00	sew-on settings, open back	






Settings with prongs: **FANCY**

Open search window:
Ctrl + F



closed back




open back



sew-on settings

The pictures show
the item in size
20/16 mm


Size	Product code	Type	Swarovski no.
14/11	01532-00-00	closed back	
	01532-10-00	open back	
	01532-40-00	sew-on settings, open back	
20/16	01531-00-00	closed back	4739
	01531-10-00	open back	
	01531-40-00	sew-on settings, open back	



closed back



open back



sew-on settings

The pictures show
the item in size
10 mm

Size	Product code	Type	Swarovski no.
5 mm	01640-00-00	closed back	
	01640-10-00	open back	
	01640-40-00	sew-on settings, open back (3x1)	
10 mm	01641-00-00	closed back	4745
	01641-10-00	open back	
	01641-40-00	sew-on settings, open back (5x1)	



Settings with prongs: **FANCY**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
19/11,5 mm

Size	Product code	Type	Swarovski no.
14/8,5	01544-00-00	closed back	  
	01544-10-00	open back	
	01544-40-00	sew-on settings, open back	
19/11,5	01543-00-00	closed back	4757
	01543-10-00	open back	
	01543-40-00	sew-on settings, open back	



Settings with prongs: **FANCY**

Open search window:
Ctrl + F



closed back




open back



sew-on settings

The pictures show
the item in size
22x12,5 mm

Size	Product code	Type	Swarovski no.
			
14/8	01583-00-00 01583-10-00 01583-40-00	closed back open back sew-on settings, open back	4760
18/10,5	01584-00-00 01584-10-00 01584-40-00	closed back open back sew-on settings, open back	4760
22/12,5	01585-00-00 01585-10-00 01585-40-00	closed back open back sew-on settings, open back	4760



closed back




open back



sew-on settings

The pictures show
the item in size
23/13 mm

Size	Product code	Type	Swarovski no.
			
18/10	01593-00-00 01593-10-00 01593-40-00	closed back open back sew-on settings, open back	4767
23/13	01594-00-00 01594-10-00 01594-40-00	closed back open back sew-on settings, open back	4767



Settings with prongs: **FANCY**

Open search window:
Ctrl + F



closed back




open back



sew-on settings

The pictures show
the item in size
32x13,5 mm

Size	Product code	Type	Swarovski no.
18/7,5			
	01580-00-00	closed back	
	01580-10-00	open back	
	01580-40-00	sew-on settings, open back	
23/10	01581-00-00	closed back	4790
	01581-10-00	open back	
	01581-40-00	sew-on settings, open back	
32/13,5	01582-00-00	closed back	4790
	01582-10-00	open back	
	01582-40-00	sew-on settings, open back	



closed back




open back



sew-on settings

The pictures show
the item in size
19 mm

Size	Product code	Type	Swarovski no.
14 mm			
	01610-00-00	closed back	
	01610-10-00	open back	
	01610-40-00	sew-on settings, open back	
19 mm	01609-00-00	closed back	4795
	01609-10-00	open back	
	01609-40-00	sew-on settings, open back	
28 mm	01608-00-00	closed back	4795
	01608-10-00	open back	
	01608-40-00	sew-on settings, open back	

< [Sitemap](#)



Settings with prongs: **FANCY**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
20/20,4 mm

Size	Product code	Type	Swarovski no.
6/6,1	01666-00-00	closed back	4799
	01666-10-00	open back	
	01666-40-00	sew-on settings, open back	
9,2/9,4	01667-00-00	closed back	4799
	01667-10-00	open back	
	01667-40-00	sew-on settings, open back	
14/14,3	01668-00-00	closed back	4799
	01668-10-00	open back	
	01668-40-00	sew-on settings, open back	
20/20,4	01669-00-00	closed back	4799
	01669-10-00	open back	
	01669-40-00	sew-on settings, open back	





Settings with prongs: **Fancy**

Open search window:
Ctrl + F



closed back



open back



sew-on settings

The pictures show
the item in size
18 mm

Size	Product code	Type	Swarovski no.
			  
8 mm	01693-00-00	closed back	4460
	01693-10-00	open back	
	01693-40-00	sew-on settings, open back	
10 mm	01694-00-00	closed back	4460
	01694-10-00	open back	
	01694-40-00	sew-on settings, open back	
14 mm	01695-00-00	closed back	4460
	01695-10-00	open back	
	01695-40-00	sew-on settings, open back	
18 mm	01696-00-00	closed back	4460
	01696-10-00	open back	
	01696-40-00	sew-on settings, open back	

< [Sitemap](#)



Flatback settings: **Round**

Open search window:
Ctrl + F



The picture show
dthe item in size
14 mm

Size	Product code	Type	Swarovski-no.
12 mm	00279-00-00	millgrain	2006
14 mm	00281-00-00	millgrain	2006
16 mm	00283-00-00	millgrain	2006
6,7 mm	0131100-00	millgrain	2028
7,5 mm	00758-00-00	millgrain	2028
11 mm	00278-00-00	millgrain	2028
6 mm	00355-00-00	millgrain	2035
20 mm	00286-00-00	millgrain	2035
6 mm	00355-00-00	millgrain	2058
8 mm	00356-00-00	millgrain	2058
10 mm	00357-00-00	millgrain	2058
16 mm	00283-00-00	millgrain	2058
20 mm	00286-00-00	millgrain	2058
8 mm	00356-00-00	millgrain	2072
10 mm	00357-00-00	millgrain	2072
12 mm	00279-00-00	millgrain	2072
2,6 mm	00362-00-00	millgrain	2090/4



Flatback settings: **Oval**

Open search window:
Ctrl + F



The picture show
dthe item in size
14/10 mm

Size	Product code	Type	Swarovski-no.
6/4	01324-00-00	millgrain	2190/4
8/6	00753-00-00	millgrain	2190/4
10/8	00754-00-00	millgrain	2190/4
14/10	00856-00-00	millgrain	2190/4

Flatback settings: **Square**



The picture show
dthe item in size
20/20 mm

Size	Product code	Type	Swarovski-no.
4/4	01101-00-00	flat	2415
10/10	00349-00-00	flat	2483
25/25	00660-00-00	millgrain	2483
8/8	51445-00-00	millgrain	2493
12/12	01561-00-00	flat	2493
20/20	01560-00-00	flat	2493
30/30	01562-00-00	flat	2493

< [Sitemap](#)



Flatback settings: **Baguette**

Open search window:
Ctrl + F



The picture show
dthe item in size
24/16 mm

Size	Product code	Type	Swarovski-no.
10/8	01558-00-00	flat	2520
14/10	01557-00-00	flat	2520
20/14	01556-00-00	flat	2520
24/16	01559-00-00	flat	4581
24/16	01559-00-00	flat	4582
24/16	01599-00-00	flat	4583
24/16	01599-00-00	flat	4584

Flatback settings: **Triangle**



The picture show
dthe item in size
6 mm

Size	Product code	Type	Swarovski-no.
4 mm	01534-00-00		4842
6 mm	01533-00-00		4842

Flatback settings: **Rhomb**



The picture show
dthe item in size
13/8 mm

Size	Product code	Type	Swarovski-no.
10/6	01555-00-00	flat	2709
13/8	01563-00-00	flat	2709

< [Sitemap](#)



Flatback settings: **Fancy**

Open search window:
Ctrl + F



The picture show
dthe item in size
27/16 mm

Size	Product code	Type	Swarovski-no.
19/11,5	01568-00-00	flat	4756
27/16	01569-00-00	flat	4756
39/23,5	01570-00-00	flat	4756



The picture show
dthe item in size
28/24 mm

Size	Product code	Type	Swarovski-no.
28/24	01553-00-00	flat	4759
38/33	01554-00-00	flat	4759



The picture show
dthe item in size
28/15,5 mm

Size	Product code	Type	Swarovski-no.
28/15,5	01595-00-00	flat	4766
38/21	01596-00-00	flat	4766



The picture show
dthe item in size
27/19 mm

Size	Product code	Type	Swarovski-no.
19/13	01578-00-00	flat	4787
27/19	01577-00-00	flat	4787

< [Sitemap](#)